

8/28/2012

8/28/2012

8/28/2012

Motor Controller Replacement Instructions

Tools needed for operation



1. Unplug the system from the outlet.
Remove bottom cover, by using the spinner bit on the 4
screwdriver screws.



Locate motor controller



3. Remove ground wire from damaged controller.



4. Note and mark the positions of the wiring for reassembly.
Remove both sets of black and white wires.



There may be a need to disconnect the 2 color
thermistor wires and the yellow door switch wire, for
easier access.



1

